



RIPRISTINO DA SCHEGGIATURA (BIANCO) - (cod. KIT02RS)



1. Superficie scheggiata




2. Contenuto Kit di ripristino




3. Allargare la scheggiatura con il tampone (E) e la carta Grana 180 (A), allo scopo di uniformare la superficie e togliere le microfratture. Carteggiare vicino alla parte danneggiata con carta Grana 320 (C).




4. Rimuovere la polvere e sgrassare la superficie utilizzando acetone o alcool




5. Perimetrare l'area da riparare con nastro adesivo crespato. Versare tutto il contenuto del catalizzatore (F) dentro il flacone dello stucco (G) e mescolare con la Paletta in Legno (H) fino ad ottenere una miscela omogenea



6. Stendere con la paletta in legno (H) sulla parte daneggiata uno strato abbondante della miscela appena preparata e lasciare riposare per 24 ore con temperatura minima 15/18°C (non bagnare)



7. Carteggiare il materiale in eccesso con tampone (E) e carta Grana 180 (A) fino a pareggiare la superficie, successivamente procedere con tampone in legno (E) e carta Grana 240 (C) per rifinire la superficie.



8. Strofinare con carta Grana 320 (C) seguendo il senso indicato per ripristinare totalmente la superficie




9. Strofinare con scotch-brite (D) seguendo il senso indicato per satinare la superficie




10. Superficie ripristinata
Il ripristino potrebbe essere percepibile


RESTORING A CHIPPED SURFACE (WHITE) - (cod. KIT02RS)



1. Chipped area.




2. Restore kit content.



3. Widen the chipped area with the wooden block (E) and 180-grit sandpaper (A) in order to smooth the surface and remove all small cuts. Polish the surface next to the damaged area with 320-grit sandpaper (C).




4. Remove dust and clean the surface with acetone or alcohol.




5. Cover the area to be repaired with masking tape. Pour the catalyst (F) into the plaster (bottle G), and stir with the wooden spatula (H) until blended.



6. Cover the area to be repaired with a plentiful layer of product with the wooden spatula (H). Let it dry for 24 hours at a minimum temperature of 15/18°C. Do not wet the surface.



7. Sand the excess with the wooden block (E) and the surface with P180 sandpaper (A) until the surface gets smooth. Go on sanding the surface with the wooden block (E) and P240 sandpaper (B) to finish the surface.



8. Sand the surface with P320 sandpaper (C) following the direction shown above to repair the surface completely.



9. Wipe the surface with a Scotch-Brite pad (D) in the direction shown above until the surface is completely smooth.



10. Restored surface. Some traces might be visible.